


REPLACEMENT SHEET

BEST AVAILABLE COPY

File(F), Edit, View, Parts, Path(P), Expansion function(X), Interference(C)
Window(W), Help(H)




Subassembly composition	Composition
Display	
Edit	
Measuring	
Interference check	
Control check	
Work completed	
Point	
Pending	
Return to just before position	
Property	

Add
Delete
Rename
Parts Exchange

Reference Plane
Work Coordinate
Reference (M)

File(F), Edit, View, Parts, Path(P), Expansion function(X), Interference(C)
Window(W), Help(H)



Selected Pats: dtm0012

FIGURE 16

Add
Delete

Edit
Offset
Displaying Section
Display Attribute
Measuring Distance

Change	Designation of lower limit	Designation of upper limit
Off set	Displaying section	Display attribute
Edit		Measuring distance




Figure 24